

How to install the Adapter kit with the MSR SuperFly and GSI Glacier camp stoves.

- 1: Place the Adventure Skottle upside down on a flat surface.
- 2: Install the gas canister to the **SuperFly** or **Glacier stove**. (Note: The photo does not have canister attached.)
- 3: Place the stove upside down on the bottom of the Skottle. (Gas canister up.)
Align the stove fins along or next to the open tab slots on the Skottle pan. (see "X" in photo)
- 4: Position the adapter with the open end of the adapter around the stove's center post.
- 5: Position the front two adapter legs into the pan's tab slots and pull the third leg into the tab slot and adjust so the adapter is centered. The stove should be secure.

