

IMAGES NOT TO SCALE E9 SLOT 1.5 H 7 W E10 SLOT 1.5 H 10 W SATIN BLACK SLOT COVER E9: 5 1/2 E10: 8 5/8 E9: 13 E10: 15 E9: 9 3/4 E10: 11 3/4 E9: 8 3/4 E9: 4 E10: 5 E10: 11 3/4 FRONT SIDE BACK

Maintenance

key from sticking.

Regular dusting and cleaning. Apply 3 in 1 oil into key way of lock a couple of times a year to prevent

## Installation Instructions

- 1 Determine the location and height of where the mailbox is to be installed. With the door open, mark the location of screw holes. Install mailbox using screws.
- 2 Mailbox door can be used with or without locking. Hardware and two keys provided.

FUORISERIE 351 37TH STREET BROOKLYN NY 11232 T: 718 643 1381 E: FUORISERIE@AOL.COM