



EXOTIC 37MM FIREBALL INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE STARTING PROJECT

- 1) Place super glue on fuse face of fireball and fuse.
- 2) While still wet dip fireball into black powder or Pyrodex
- 3) Prime a 37mm hull by placing a #209 shotgun primer in the hole on the flat side of 37mm casing
- 4) Place glue on the bottom of a powder bushing and push it into the bottom of the casing.
- 5) Measure out 60 grains of Pyrodex and add it into the casing inside the bushing.
- 6) Cut the fuse on the end of the fireball at about $\frac{1}{2}$ " with a sharp knife at a 45 degree angle.
- 7) Push the Fireball fuse side down into the casing on top of the bushing.
- 8) Place the colored pushing disc down the casing on top of the fireball and fill the casing directly on top of the pushing disc with $\frac{1}{2}$ " of hotglue.
- 9) It is now ready to fire.

