


WIRETAP

QUICKSTART GUIDE



1. Connect your combination headphones + mic headset, or other TRRS accessory (such as a Square reader or a [Backbeater](#) sensor) to the connector with the  icon.



2. Connect any pair of headphones. The mic channel is not available on the second connector.



3. Plug Wiretap into your phone's combo jack. Audio goes out through both connectors, and mic or other input comes in through the first connector. **Note:** for best results, always plug accessories into Wiretap before connecting to your phone.