

MK ADVANCED STONE SEALER

DIRECTIONS: Read entire label before using. Follow steps as directed. Make sure surface is clean, and free of waxes and coatings. Test a small inconspicuous area to determine ease of application and desired results. Allow new grout installations to cure for a minimum of 72 hours before proceeding.

STEP 1: Protect any adjacent surfaces not intended to be treated.

STEP 2: Thoroughly clean surfaces with MK Neutral Floc Cleaner, MK Multi-Surface Cleaner (for countertops, walls, ledges, etc.) or MK Intensive Cleaner (for heavily soiled surfaces) and allow to dry completely.

STEP 3: Liberally apply MK Advanced Stone Sealer with an MK Sealer Applicator, low pressure sprayer, paint brush, paint pad or roller until the surface is completely covered. **IMPORTANT:** Do not allow sealer to puddle.

STEP 4: Allow MK Advanced Stone Sealer to absorb for approximately 5 minutes, then buff dry with a clean towel.

STEP 5: A second application may be necessary for more porous surfaces. Allow the first coat to dry 30-45 minutes and then repeat steps 3 and 4.

STEP 6: Regular foot traffic or use may resume within 3-5 hours. For best results, keep the treated surface free from any liquids or soiling for 48 hours. Sealer cures completely within 72 hours.



MK Advanced Stone Sealer

is another custom blended product made in the USA for

Marble Kare Products, Inc.

