




## Push Side Fitting - Transom Overhead Frame Installation





Spärka UK

T: 0114-350-3414 | E: sales@sparkauk.com | www.sparkauk.com



## Push Side Fitting - Transom Overhead Frame Installation

## Code: S-10

