



AutoFlare's Installation Process Guidelines: Head Light and/or Tail Light Trims

**Please note the following is a general guide only for all models sold by AutoFlare. Due to the different style/design and fitting locations, small adjustments will need to be made.*

Tips:

- *Allow yourself enough time (approx. 30 minutes) for the installation process of head light and/or tail light trims. We don't want you to rush the process to be disappointed with the installation outcome. Rushing the application of the trims onto your ride could potentially result in poor fitment or misalign for the longevity of the part and its fitment.*
- *Do not install the head light and/or tail light trims if your ride has gotten wet within the past 24 hours.*
- *When installing in cold weather, we recommend using a heat gun to warm both trims before applying to either the Headlight or Tail Light of your ride.*
- *Use the correct tools! Paintwork damage can easily happen when incorrect tools have been used.*

Tools Required:

- A razor blade
- Heat gun

Consumables Required:

- Adhesion promoter
- Car polish
- Microfibre cloth
- Double Sided Tape (Supplied)
- Masking tape

Step 1: Preparation (it's all about the prep!)

Remove any parts that may interfere with installing process of the trims.

Thoroughly wash your head lights and/or tail lights (for cars with dirt and grime embedded on the surface of the light, a clay cloth should be used to remove before install).

Follow by polishing the area after the lights are dry to create a clean surface for application of the trims.

Step 2: Installation

Place trims onto the light. Use the masking tape to mark the location of the trims on the lights.

Remove and apply adhesion promoter on the light. Leave masking tape in place to use as a guide to install the trim (where possible).

Turn on heat gun and wave the heat over the double-sided tape to activate the glue.

Peel off all double-sided tape.

Using the masking tape as a guide carefully lay the trims on, lightly and firmly press allowing the double-sided tape to complete contact with the light.

Repeat the process for the other light.

Questions: If you require any further information or have inquires relating to the instalment process of our head light or tail light trims, please send us an email at info@autoflare.com.au. We are more than happy to assist.

AutoFlare will not be held liable for any incorrect installations (that being not applied correctly or issues in future) or damage caused to parts occurring during the instalment process.