

Parts Supplied:

- Catch Can Shell
- Catch Can Top Piece
- Catch Can Base
- 140 O-Ring x 2
- Breather Filter
- M8 x 90mm Cap Head Bolt
- Yamaha Catch Can Silicone Hose
- 2 x 18-32mm Hose Clamps
- 3 x M6 x 12mm Bolts
- M6 Washer
- 3/4" (19mm) Plastic Joiner
- 4 x 150mm Zip Ties
- 1/4" BSPP Plug
- 011 O-Ring
- Catch Can Bracket

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

INSTALLATION INSTRUCTIONS:

1. Make sure ski is secure and on a flat surface. Remove lanyard and disconnect battery.
2. Remove seat housing to gain access.
3. Remove seat support plastic or any plastic that may prevent access.
4. Assemble the catch can as pictured using supplied hose clamp to attach breather to the correct side and bracket using M6 bolts.



5. Using 10mm spanner, remove bolts shown. Be careful to catch bracket.



6. Place Bracket over OEM bracket

7. Reinstall OEM Bolts and tighten



8. Install supplied M6 Bolt with washer on right hand side of mounting bracket



9. Install hose provided and secure with hose clamp to the catch can.



10. Unplug breather hose from oem Outlet (located on supercharger hose) NOTE: Block off if not using aftermarket Air Filter.



11. Connect breather Hose to catch can hose with supplied 3/4" joiner and zipties



12. Ensure regular check up's on your catch can and empty as required.

