

# WORX INTAKE GRATE

Part No. WR250

Suits Models:  
• SEADOO RXTX / GTX 2018+ ST3 HULL

**Parts Supplied:**

- WR250 Intake Grate

**Tools Required:**

- 13mm Socket Wrench
- Marine Silicone Sealant

***IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION***

## INSTALLATION INSTRUCTIONS:

1. Remove stock intake grate using a 13mm socket and clean the hull, gently using a flat bladed screwdriver or scraper to remove any old sealant.
2. Apply Marine silicone sealant around mounting holes, rear mount surfaces and edges of the new Worx intake grate. More sealant will make the intake grate harder to remove in future but will also prevent cavitation.
3. Fit the Worx intake grate into position and secure using your OEM bolts. Blue Loctite can be used on the bolts before inserting to ensure they stay firmly tightened.
4. Wipe away any excess sealant around the edge of the grate using a cloth. We recommend waiting 24 hours to the sealant to properly cure before riding.
5. Regularly check that all bolts are tight on your intake grate after every few rides.

**Australia:**

10B 354 Brisbane Rd Arundel QLD 4214  
Phone: +61 7 5563 1031  
info@worx.com.au | worx.com.au

**United States:**

9251 Orco Parkway Unit G, Riverside CA 92509  
Phone: (951) 684-9679  
info@worxracingusa.com | worxracingusa.com