

**Parts Supplied:**

- 2 x WORX Racing adjustable sponson paddles
- 2 x WORX Racing Backing rails
- 2 x 8mm x 19mm Flat washers
- 8 x ¼ x 1¼ Button head bolts
- 14 x ¼ x ¾ Flat Washers

**IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION****INSTALLATION INSTRUCTIONS:**

1. Make sure ski is secure and on a flat surface. Remove lanyard.
2. Remove stock sponsons using 10mm and 13mm Socket wrench taking off nyloc nuts and washers to remove OEM sponson clean hull of OEM silicone and residue.
3. Apply a bead of Marine Sikaflex sealant around the edges of the Backing rails, and around each of the mounting holes (Four on each side).
4. Fit the backing rails to both sides of the boat using stock nyloc nuts and 6 of the ¼ x ¾ washers and 2 x 8mm x 19mm Flat washers for large bolts on each side.
5. Fit the sponsons paddles using the remaining (¼ x 1¼) bolts with the (¼ x ¾) flat washers supplied (start all of the bolts into the side rail before tightening).
6. After riding for about 15 minutes check that your sponson bolts are tight and when you have decided which position best suits your riding style it is recommended that you apply a layer of silicon between the side rails and the sponsons and also apply loctite to the mounting bolts.
7. Regularly check that the sponson fixing bolts are tight. Warning: These sponsons will vastly improve the turning capability of your boat. Take time to get used to them before you attempt any hard cornering

**Australia:**

10B 354 Brisbane Rd Arundel QLD 4214  
Phone: +61 7 5563 1031  
info@worx.com.au | worx.com.au

**United States:**

2440 Kiowa Blvd. N, Lake Havasu City, AZ 86403  
Phone: (928) 302-3516  
info@worxracingusa.com | worxracingusa.com