

WORX SPONSONS

Part No. WR528

Suits Models:
• KAWASAKI SXR

Parts Supplied:

- 2 x WORX adjustable sponsons paddles
- 8 x 3/16 x 5/8 Flat Washers
- 8 x 3/16 x 1 Button head bolts

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

INSTALLATION INSTRUCTIONS:

1. Using an electric drill with a 3/16" drill bit drill out the rear four rivets holding on the side and rear mouldings, clean out the holes in the hull.
2. Fit the WORX sponsons using the 8 x 3/16" x 1 Allen head bolts and the flat washers. Apply a small amount of the blue loctite to each bolt. Be careful to start all of the bolts into the sponsons before you tighten.
3. Warning: These sponsons will vastly improve the turning capability of your boat!
4. Take time to get used to them before you attempt any hard cornering.

Australia:

10B 354 Brisbane Rd Arundel QLD 4214
Phone: +61 7 5563 1031
info@worx.com.au | worx.com.au

United States:

2440 Kiowa Blvd. N, Lake Havasu City, AZ 86403
Phone: (928) 302-3516
info@worxracingusa.com | worxracingusa.com