

Parts Supplied:

- 2 x WORX adjustable sponsons paddles
- 6 x 3/16 x 5/8 Flat Washers
- 6 x 3/16 x 1 Button head bolts
- 6 x 3/16 Nyloc nut

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

INSTALLATION INSTRUCTIONS:

1. Remove the three rear bolts with a Phillips screw driver and 8mm spanner. Install one 3/16 x 1 bolt and 3/16 nyloc nut to rear hole and tighten. Mark the 2 forward holes on the outer side of the rail. Using the electric drill with the 3/16" drill bit, drill out the holes marking marked from sponson in the hull side rail.
2. Fit the WORX sponsons using the 8 x 3/16" x 1 Allen head bolts and the flat washers with 3/16 nyloc nuts. Apply a small amount of the blue loctite to each bolt. Be careful to start all of the bolts into the sponsons before you tighten
3. Warning: These sponsons will vastly improve the turning capability of your boat!
4. Take time to get used to them before you attempt any hard cornering.

