



WORX RACING INTAKE GRATE

PART # - WR207

MODELS: SEADOO SP/ SPI/ SPX/ PRE 97 XP

INSTALLATION INSTRUCTIONS

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Parts Supplied:

1 x **WORX WR207 Intake Grate**
2 x 20mm x 6mm Allen Head Bolts
2 x 12mm x 6mm Allen Head Bolts

- 1- Put ski on a flat surface. Remove intake grate, wipe clean any old silicone and residue from hull.
- 2- Apply a small amount of Marine silicone sealant to both mounting surfaces of your new **WORX Intake Grate**.
- 3- Fit **WORX Intake Grate** into position using the Allen Headed bolts supplied.
Important Use the shorter (M6 x12mm) bolts in the rear mounting holes.
Failure to do this could cause damage to pump housing, tighten bolts.
- 4- Wipe off excess sealant with a damp cloth. Allow 24 hours minimum for sealant to cure before riding.
- 5- Regularly check all bolts are tight on your intake grate.

Thank you for purchasing **WORX Racing components** products. We firmly believe that **WORX Racing Components** products are among the finest watercraft parts available. A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure. If you have any questions or comments on the performance and/or installation of our products please contact us at the numbers listed on page one or through your local **WORX** dealer.

10B 354 Brisbane Rd Arundel QLD 4214 Phone: +61 7 5563 1031

www.worx.com.au / info@worx.com.au
