



WORX RACING INTAKE GRATE

PART # - WR238

MODELS: SEADOO RXPX 2012 +

INSTALLATION INSTRUCTIONS

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Tools: 13mm socket Wrench
Tube of Marine silicone sealant

Parts Supplied: 1 x **WORX WR238 Intake Grate**

- 1- Remove stock intake grate and clean hull of old silicone and residue
- 2- Apply Marine silicone sealant around mounting holes on WORX intake grate and around rear mount surfaces and edges of intake grate.
- 3- Fit WORX intake grate into position using OEM bolts
- 4- Wipe away excess sealant with cloth. Allow 24 hours for sealant to cure before riding
- 5- Regularly check that all bolts are tight on your intake grate.

Thank you for purchasing **Worx Racing components** products. We firmly believe that **Worx Racing Components** products are among the finest watercraft parts available. A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure. If you have any questions or comments on the performance and/or installation of our products please contact us at the numbers listed on page one or through your local **Worx** dealer.

10B 354 Brisbane Rd Arundel QLD 4214 Phone: +61 7 5563 1031

www.worx.com.au / info@worx.com.au
