



WORX RACING SPONSONS

PART # - WR546

MODELS: HYDROSPACE S4/ YAMAHA WAVEBLASTER 1

INSTALLATION INSTRUCTIONS

IMPORTANT: READ ALL INSTRUCTIONS BEFORE PROCEEDING WITH INSTALLATION

Parts Supplied:

- 2 x **WORX** adjustable sponsons paddles
- 6 x 3/16 x 1 Button head bolts
- 6 x 3/16 x 5/8 Flat Washers
- 6 x 3/16 Nyloc nuts

- 1- Using the electric drill with the 3/16" drill bit drill out 3 holes into the rear flange. Use the pre drilled rear sponson hole as a guide. Clean out the holes in the hull. Drill same holes in the paddles.
- 2- Fit the **WORX** sponsons behind bond rail using the 6 x 3/16" x 1 Allen head bolts and the flat washers. Apply a small amount of the blue loctite to each bolt. Be careful to start all of the bolts into the sponsons before you tighten.
- 3- **Warning:** These sponsons will vastly improve the turning capability of your boat! Take time to get used to them before you attempt any hard cornering.



Thank you for purchasing **WORX Racing Components** products. We firmly believe that **WORX Racing Components** products are among the finest watercraft parts available. A great deal of time and effort has gone into the design and development of this product to ensure that it will perform to the highest standard and that installation is a relatively straight forward and simple procedure. If you have any questions or comments on the performance and/or installation of our products please contact us at the numbers listed on page one or through your local **WORX** dealer.

10B 354 Brisbane Rd Arundel QLD 4214 Phone: +61 7 5563 1031

www.worx.com.au / info@worx.com.au
