



www.K5OptimaStore.com

Kia Optima Carbon Fiber Mirror Covers

Overview

In these instructions, we are going to explain how to install your Karbon Concepts Mirror Covers. We will first go over how to remove your OEM Mirror covers.

PROFESSIONAL INSTALLATION IS RECOMMENDED! Please read through these instructions prior to installing your diffuser. If at any point, you do not feel comfortable with the instruction provided, please contact a performance shop to arrange for installation.

Tools Needed:

1. Fingertips
2. 3M Tape. (Supplied and installed)
3. Black Plasti-dip (unless you have own a black car)

Instructions

Removal:

1. Start by removing the stock mirror cover in order to prep it for paint and/or plasti-dip. There are 6 tabs on the inside of the mirror housing. Your basic goal is to pull towards the front of the vehicle using your fingertips. Start with the #1 and then work your way over. You want to be gentle but you'll realize that you have to give it a firm tug. You can also use a plastic panel popper tool in order to help facilitate this process.

K5 OPTIMA

S T O R E

www.K5OptimaStore.com



2. Once you have the cover off, begin spraying with Plasti-dip. Please follow the directions supplied on the can as this is best.
3. Be sure to coat the inside lip that tucks underneath the mirror housing in order to get all areas covered. If you put the housing on and notice there are some areas still showing color, you can always go back and re-spray.
4. Place the cover back onto the vehicle by pressing it firmly into place the same way that you took it off.

K5 OPTIMA

S T O R E

www.K5OptimaStore.com



5. Peel the backing off of the supplied 3M tape on the inside of the mirror cover.
6. Being very careful, align the mirror cap with your turn signal from the front.



7. Press down firmly on the taped surfaces to guarantee adherence.
8. Enjoy your new Carbon Fiber Mirrors!!!