

BEFORE YOU BEGIN

Do not apply on vinyl or textured walls. Only apply on a flat, smooth and clean surface. We advise applying a coat of primer and a coat of paint to your walls in order to avoid possible residue or paint peeling upon removal. Ideal paints are of white or light colour with a semi-gloss or gloss finish.

PLEASE READ CAREFULLY BEFORE INSTALLING YOUR WALLPAPER MURAL.

If the surface has been freshly painted, please wait at least 1 week for the paint to fully cure. Bubbles can occur if the paint is still outgassing/flashing off.

Installation is recommended no longer than 2 weeks after receipt. No warranty will be valid if installation is past 4 weeks.

Unless you chose the "lamination" option (protective coating), only use a dry cloth or duster to clean your mural. Do NOT use water, soap or chemicals to clean your wall mural!

WHAT YOU WILL NEED

A trimming tool (Xacto knife).

A rubber or soft squeegee.

A short ladder or stepping stool.

A dry cloth.

A measuring tape.

See next page for step-by-step installation guide.



STEP 1: PREPARE YOUR WALL

Proper preparation of your wall is critical! Repair any visible defects, smooth out bumps and patch holes to ensure your wall is smooth and flat. If possible, remove all picture hooks, light fixtures and switch plates. Wash off any dirt, hair, dust or residue from old wallpaper with a dry cloth or a duster. Do NOT use water to clean your wall before application. A perfectly clean, dry wall will help the adhesive backing to keep its stickiness if repositioning is required.

PLEASE READ CAREFULLY BEFORE INSTALLING YOUR WALLPAPER MURAL.

STEP 2: GETTING READY

We recommend 2 people to install your wall mural.

Open the sturdy Eazywallz packaging tube. Inside you will find your wall mural. Look for the panel number on the back of each one. Panel #1 is the first panel on the left. Unroll all panels and lay them flat on the floor, the printed side facing the ceiling. You may notice creases and/or bubbles as you unroll the panels. No worries, this is normal. The creases will disappear once the mural is flattened on the wall. If you purchased a wall mural that is smaller than your actual wall size, take the measurements of your wall to center it. Then draw a guideline, just like you would to hang a poster or framed photograph.

STEP 3: PEEL IT

Peel off the liner a few centimetres only across the top of the first panel. Do not peel off the entire liner all at once.

STEP 4: STICK IT!

Remember that the success of the installation will depend on properly placing the first panel. Stick the top left corner of the panel to the top left corner of your wall. This is the easiest place to start.

Using a smoothing tool or squeegee, smooth the top of the panel onto the wall. Do not use pressure to avoid any scratches.

Peel off the rest of the panel by gradually and evenly pulling down the liner, a few centimetres at a time. We recommend having another person hold the bottom of the panel as you work your way down.

Once the first panel is applied, and if necessary, remove any bubbles by gently pushing them outward with the squeegee.



STEP 5: ADDITIONAL PANELS

Start by aligning Panel #2 to Panel #1. Simply stick the panel against the edge of the first one, by matching the pattern of the mural. Follow STEP 4 above to apply the rest of Panel #2.

PLEASE READ CAREFULLY BEFORE INSTALLING YOUR WALLPAPER MURAL.

Repeat the same process to apply all additional panels.

STEP 6: TRIM OVERAGE

Once all panels have been applied, SLOWLY trim all the overage with an utility knife with a sharp blade (ie: Xacto knife). Follow the edges of your wall or ceiling to do so. You can also use a ruler to cut through a straight line.

If needed, repeat this process to cut around outlets (if not removed prior to installation), fuse boxes, windows, doors, etc.

Repeat the same proces