

PREPASTED

BEFORE YOU BEGIN

This wall paper is prepasted—requiring only water to activate the glue—and is designed for easy application and clean removal. In addition to the instructions below, you may be interested in more detailed information on hanging wall paper.

PREPARE THE WALL

The wall surface should be clean, dry, structurally sound and free of mildew, grease, or other stains, and free of irregularities in order to achieve the best hanging performance and complete removal when redecorating.

To apply on a drywall

For best results, apply to a wall surface that has been painted with one coat of builder's primer and one coat of latex paint (note: this is typical of new construction; a wall surface that has been painted with a single coat of primer or a coat of satin or gloss paint is acceptable). The wall surface should be clean, smooth, and free of debris or contaminants.

To apply on a painted wall

Painted walls should be primed, smooth, and free from debris. Check the wall surface to determine the condition of the paint adhesion. If the paint is old, damaged, or flaking, priming is highly recommended.

To apply to a wall previously covered with wall paper

Any old remaining wallpaper should be removed as well as the old adhesive (remove by sanding or using adhesive remover). Primer should be applied to the wall surface that is clean, smooth, and free of the old adhesive.

To apply over paneling

Any grooves should be filled to achieve a smooth surface, then covered with an adhesion-promoting primer.

To apply to a wall currently covered with wallpaper.

Not recommended. Results will not be ideal.

PREPASTED

APPLY THE WALLPAPER

Our non-woven prepasted matte and satin finish wallpapers do not require the application of any glue, but rather a simple water spray onto the back using a standard spray bottle.

Be careful not to spray too much water onto the paper in order to prevent the glue from leaking. Should any glue leakage occur, delicately and immediately wipe them away using a dampened sponge.

Our non-woven wallpapers do not shrink like traditional wallpapers.

It is advised that 2 people complete the installation process together. Be careful when positioning the panels to not fold them so that no marks appear during installation. After precisely positioning the panel onto the desired area on the wall, press the glue down outward from the centre of the wall toward the exterior in order to eliminate bubbles and ensure the glue spreads properly. Trim any excess paper using a box cutter or Xacto knife, and with the help of a sharp-edged ruler.