

REMOVABLE PHOTOTEX

BEFORE YOU BEGIN

To install over Plaster

Preparing your surface properly is the most essential part of the process. Make sure it is properly prepared, clean, dry and has no loose plaster or dust on it. The surface must be untextured and smooth. If your surface is porous, treat it first with a quality primer or sealer to ensure ideal results.

To apply over a Painted Surface

We recommend that you install over matte emulsion paint only. If you have an old painted surface with any loose paint particles or flakes, we advise that you first properly prepare it for best results. If your surface is porous, we recommend first treating it with a primer or sealer before continuing with the installation process. If your surface has recently been painted, please allow 2 to 3 weeks for it to fully dry before proceeding to install your Removable Phototex.

To apply over a Paper Surface

Remove any old paper, as the new wallpaper may not otherwise stick down properly. Do NOT use lining paper underneath this material.

CHECK YOUR MURAL/SKIN

Please carefully check your entire mural/skin before beginning the installation process. Lay the panels out and let them rest for a minimum of 5 hours. If you notice any material or image defects, STOP EVERYTHING AND CONTACT US. DO NOT INSTALL THE MURAL/SKIN.

OTHER

Do not pre-trim your mural/skin before installing.