

2002 HONDA RC-51 FENDER ELIMINATOR INSTRUCTIONS

CAUTION: STAINLESS STEEL EDGES CAN BE SHARP!

NOTE: MODIFICATIONS MAY NOT BE LEGAL IN SOME STATES

1. REMOVE SEAT (LIFT REAR CORNERS TO EXPOSE BOLTS).
2. REMOVE TAIL SECTION- 2 SCREWS AT FRONT SIDES, 2 BUNGEE HOOKS, 2 PLASTIC RIVETS ON UNDERSIDE (PRY OUT). DRILL OUT RIVETS HOLDING SIDE REFLECTORS.
3. REMOVE TURN SIGNALS AND SEAT LATCH LOCK (PULL OUT CLIP AND LIFT CABLE FROM MOUNT). REMOVE RUBBER BANDS FROM STORAGE AREA.
4. UNPLUG LICENSE PLATE LIGHT AND TAIL LIGHT, MOVE WIRES FORWARD AND OUT OF WAY.
5. MAKE CUT TO UNDERSIDE OF FENDER AS SHOWN IN FIG. A. USING A UTILITY KNIFE, CUT STRAIGHT ACROSS COMPLETELY SEPERATING THE REAR OF FENDER.
6. REMOVE LICENSE PLATE LIGHT AND LICENSE PLATE FROM STOCK FENDER.
7. REMOVE PLASTIC COLLAR FROM AROUND TAIL LIGHT.
8. ASSEMBLE PARTS AS SHOWN IN FIG. C&D. TURN SIGNALS MOUNTS AND TURN SIGNALS ARE SHOWN IN PLACE IN FIG. E. RUN TURN SIGNAL WIRES UP THROUGH GROMMETS IN BOTTOM OF PAN. LEAVE NUTS LOOSE UNTIL ENTIRE ASSEMBLY IS SET IN PLACE IN FRAME AS SHOWN IN FIG. C. USE THE 6m X 25m BOLTS SUPPLIED TO ATTACH SIDE MOUNTS TO FRAME, USE A WASHER ON EACH SIDE OF BOLT. BE SURE TO USE THE STOCK MOUNTING GROMMETS FOR THE TAIL LIGHT. ONCE IN PLACE, ALIGN EVERYTHING AND THEN TIGHTEN NUTS. THE LOCK ASSEMBLY FOR THE SEAT LATCH CAN BE A LITTLE TIGHT ON INITIAL INSTALLATION BUT BY WORKING BACK AND FORTH A BIT AS YOU PUSH IN PLACE, IT WILL GO.
9. PLUG ALL WIRES TOGETHER. IF USING ASSIMILATOR SEE SEPERATE INSTRUCTIONS. BLUE WIRE GOES TO RIGHT TURN SIGNAL, ORANGE TO THE LEFT. BE SURE TO USE THE 2 RUBBER GROMMETS SUPPLIED TO RUN WIRES UP THROUGH BOTTOM OF PAN. RE-ATTACH CABLE TO SEAT LATCH, BE SURE CABLE IS SNUG IN IT'S BRACKET. AT THIS POINT CHECK ALL LIGHTS FOR PROPER OPERATION.
10. SET BODY WORK IN PLACE CAREFULLY SO AS NOT TO SCRATCH. CHECK THAT EVERYTHING IS LINED UP PROPERLY, IF NOT SOME NUTS MAY NEED TO BE LOOSENED TO ALLOW ALIGNMENT. BE SURE SEAT LATCH CABLE IS PROPERLY ATTACHED AND FUNCTIONAL BEFORE SHUTTING LID OR ATTACHING REAR SEAT.
11. INSTALL 2 PLASTIC RIVETS SUPPLIED, (OR USE STOCK ONES IF NOT RUINED), BACK UNDERNEATH ON EACH SIDE.

PARTS LIST: MAIN PAN, LICENSE PAN, LICENSE LIGHT BRACKET, 2 – TAIL LIGHT BRACKETS, 2 ALUMINUM SIGNAL BRACKETS, 2 – 6m X 25m BOLTS, 2 – 6m NUTS, 8 – ½” SCREWS, 8 – ½” NUTS, 10 – WASHERS 2 – SMALL GROMMETS, 4 CONNECTORS, 2 – PLASTIC RIVETS, 1 SET OF TURN SIGNALS. (LTD KIT COMES WITH ASSIMILATOR, LESS SIGNALS AND SIGNAL BRACKETS.

