

HONDA F-4i FENDER KIT INSTRUCTIONS

CAUTION: STAINLESS STEEL EDGES CAN BE SHARP!

1. REMOVE SEATS AND TAIL SECTION, 2 SIDE BOLTS (BUNGEE HOOKS), 2 ALLEN SCREWS FRONT SIDES, 4 PLASTIC RIVETS UNDERNEATH ALONG SIDES (UNSCREW AND THEN PRY OUT). SLIDE OFF TAIL SECTION, UNPLUG SIGNALS, TAIL LIGHT, AND LICENSE PLATE LIGHT. REMOVE KEY LATCH (CAREFULLY PRY OPEN THE 2 EARS ON CLIP WITH SMALL SCREWDRIVER TO REMOVE).
2. MARK AND CUT FENDER AS SHOWN. IT LOOKS MORE COMPLICATED THAN IT IS. START CUT UP SIDE USING ANY SUITABLE CUTTING DEVICE(A HACKSAW BLADE WILL WORK FINE) DON'T WORRY ABOUT CUTTING THROUGH TO THE INSIDE OF STORAGE AREA, IT'S SUPPOSE TO. FOLLOW THE BOTTOM EDGE OF THE FLANGE THATS MOLDED IN THE FENDER, CUT MOST OF THE WAY BACK, NEXT CUT STRAIGHT DOWN AS SHOWN, BE SURE YOUR BEHIND THE FENDER MOUNTING POINT.
3. MOUNT SIGNAL BRACKETS TO LICENSE PLATE BRACKET , THEN MOUNT TO MAIN PAN MOUNTING BRACKETS AND TAIL LIGHT MOUNTING BRACKETS (DO NOT TIGHTEN). PUT STOCK GROMMETS IN TAIL LIGHT MOUNTS THEN THEN MOUNT TAIL LIGHT USING STOCK HARDWARE.
4. DRILL HOLE FOR CABEL BRACKET AND BACKING BRACE AND INSTALL USING 1/2" BOLT.
5. SLIDE LOCKING MECHANISM UP THROUGH LICENSE PAN AND MAIN PAN (WORKS EASIEST IF YOU SLIGHTLY ROUND THE EDGES FIRST). SLIDE LICENSE PLATE LIGHT MOUNT DOWN FROM ABOVE CLIP INTO PLACE WITH STOCK CLIP. MOUNT LICENSE PLATE LIGHT.
6. PUT IN THE GROMMETS FOR SIGNAL WIRES. INSTALL SIGNALS PUTTING WIRES UP THROUGH GROMMETS.
7. UNBOLT BLACK FENDER AT REAR. SLIDE ENTIRE KIT UP INTO PLACE , MOUNT WITH ORIGINAL BOLTS AND SUPPLIED WASHERS TO FRAME. CENTER KIT
8. DRILL TWO HOLES AT FRONT OF KIT INTO PLASTIC, SECURE WITH TRUSS HEAD SCREWS. ATTACH CABLE TO CABLE MOUNT. ALIGN AND TIGHTEN TAIL LIGHT., REPLACE BODY WORK, INSTALL ALL SCREWS AND PLASTIC RIVETS. RECONNECT ALL WIRES AND RUN THEM BEHIND LIGHT AND OUT OF THE WAY. CHECK FOR PROPER INSTALLATION, CHECK LOCKING MECHINISM FOR PROPER MOVEMENT. INSTALL SEATS.

CONTENTS: 1- MAIN PAN, 1- LICENSE PAN, 2- SIGNAL BRACKETS, 2- MOUNTING BRACKETS, 2- TAIL LIGHT MOUNTS, 1- LICENSE LIGHT MOUNTING BRACKET, 1- CABLE MOUNT/BACKING PLATE, 2- SMALL GROMMETS, 6- 6X12 ALLEN BOLTS, 2- 3/4" HEX BOLTS, 1- 1/2 HEX BOLT, 14- WASHERS, 6- 6MM NUTS, 5- 1/4" NUTS.

