

250 NINJA

CAUTION: STAINLESS STEEL EDGES ARE SHARP.

1. REMOVE SEAT.
2. REMOVE THE FOUR BOLTS UNDERNEATH THE TAIL SECTION THAT SECURES THE REAR FENDER, UNPLUG THE WIRES AND REMOVE.
3. BOLT INNER FENDER PAN FROM KIT UP IN PLACE OF FENDER AND SECURE WITH SAME FOUR BOLTS, GENTLY FORM PAN AS YOU PUSH UP INTO PLACE.
4. REMOVE THE TWO BOLTS UNDERNEATH THE TAIL LIGHT AND MOUNT LICENSE BRACKET FROM KIT ALONG WITH SIGNAL BRACKETS USING THE 25M BOLTS AND WASHERS SUPPLIED IN KIT. (DO NOT TIGHTEN YET).
5. MOUNT LICENSE PLATE USING YOUR BOLTS AND NUTS.
6. REMOVE TURN SIGNALS FROM STOCK FENDER.
7. PRY OUT LARGE TURN SIGNAL GROMMETS FROM STOCK FENDER AND USE ALONG WITH THE METAL WASHER TO MOUNT TURN SIGNALS (FIG. 1).
8. FEED TURN SIGNAL WIRES UP THROUGH GROMMETS IN THE INNER FENDER AND CONNECT (GREEN WIRE IS FOR LEFT TURN SIGNAL).
9. TIGHTEN ALL BOLTS.
10. REMOVE THE TAIL LIGHT LENSE (TWO PHILLIPS SCREWS IN FACE). CAREFULLY POP OUT THE SOLID PLATE IN BOTTOM OF TAIL LIGHT LENSE AND REPLACE WITH ACRYLIC COVER FROM KIT. PEEL OFF PAPER TO EXPOSE ADHESIVE AND ATTACH TO BOTTOM OF LENSE.

FIG. 1

