



COMPETITION WERKES

EX 500

CAUTION: STAINLESS STEEL EDGES ARE SHARP, USE CAUTION.

1. REMOVE SEAT AND SIDE COVERS.
2. REMOVE HANDRAIL.
3. UNBOLT PAINTED TAIL SECTION (TWO BOLTS) REMOVE BY PULLING BACK, UNPLUG WIRES.
4. REMOVE PLASTIC FENDER (4 BOLTS).
5. MOUNT NEW PAN IN PLACE OF FENDER USING TWO NEOPRENE COATED WASHERS IN BETWEEN PAN AND MOUNT AS SHOWN.
6. MOUNT TURN SIGNALS AS SHOWN AND ROUTE WIRES UP THROUGH GROMMETS IN PAN, GREEN WIRE GOES TO LEFT SIGNAL.
7. ATTACH TAIL SECTION, CONNECT REMAINING WIRES. CHECK SIGNAL AND TAIL LIGHT OPERATION.
8. MOUNT LICENSE PLATE, ATTACH HANDRAIL, SIDE COVERS, AND SEAT.

