

CAUTION: STAINLESS STEEL EDGES CAN BE SHARP!

1. REMOVE REAR SEAT
 2. REMOVE THE 4 ALLEN HEAD BOLTS INSIDE CARGO AREA HOLDING ON THE REAR FENDER. REMOVE 4 PLASTIC RIVETS FROM UNDERNEATH ALONG SIDES OF TAIL SECTION. TO REMOVE RIVETS, PRY UP EDGE WITH FINGERNAIL OR SMALL BLADED SCREWDRIVER THEN INSERT LARGER BLADED SCREWDRIVER AND CAREFULLY PRY OUT. PULL DOWN PAINTED UNDER ENCLOSURE ENOUGH TO UNPLUG WIRES SO THAT FENDER CAN BE REMOVED.
 3. CUT HOLE IN BOTTOM OF CARGO AREA BY HEATING UP ½" ALUMINUM TUBE PROVIDED AND HOLDING WITH PLIER INSERT THROUGH THE CENTER HOLE UNDERNEATH IN THE UNDER ENCLOSURE AND PUSH UP UNTIL IT MELTS THROUGH BOTTOM OF CARGO AREA, THIS IS WHERE THE LICENSE PLATE LIGHT WILL BE INSTALLED.
 4. DISASSEMBLE LICENSE PLATE LIGHT SO THAT YOU JUST HAVE THE RUBBER PLUG, BULB, AND WIRES.
 5. BOLT **SIGNAL BRACKETS** (IF USING TURN SIGNALS) AND LICENSE PLATE TO **LICENSE PAN** USING 2 PAN HEAD SCREWS (NO WASHERS) AND ATTACH SIGNALS. SET ASSEMBLY UP AGAINST UNDER ENCLOSURE AND LINE UP THE 4 MOUNTING HOLES, MARK WHERE TO DRILL EITHER ONE CENTER HOLE OR TWO SIDE BY SIDE FOR TURN SIGNAL WIRES TO PASS THROUGH.
 6. PULL OUT RUBBER PLUG IN CARGO AREA AND PASS LICENSE PLATE WIRES THROUGH AND CONNECT. FEED SIGNALS WIRES IN THROUGH HOLE OR HOLES DRILLED AND CONNECT (GREEN WIRE TO RIGHT, BROWN TO LEFT)
 7. CHECK AND BE SURE ALL LIGHTS WORK PROPERLY BEFORE CONTINUING.
 8. BOLT **LICENSE PAN** ASSEMBLY WITH **ALUMINUM SPACER** TO MOUNTING HOLES USING THE 4 TRUSS HEAD SCREWS PROVIDED. USE THE LONGER ONE IN ONE OF THE REAR HOLES DON'T USE ANY WASHERS, BOLTS GO IN FROM UNDERNEATH.
 9. REMOVE BULB FROM LICENSE PLATE LIGHT AND PUSH RUBBER PLUG INTO LARGE HOLE IN **MOUNTING BRACKET**. USE A LITTLE VASALINE OR SPIT TO LUBRICATE. INSTALL BULB AND SET DOWN THROUGH HOLE MADE IN CARGO AREA AND ATTACH **MOUNTING BRACKET** TO THE LONGER BOLT STICKING UP USING 2 WASHERS UNDERNEATH TO ACT AS SPACERS AND ONE ON TOP. ADJUST IF NECESSARY SO THAT BULB DOESN'T TOUCH **LICENSE PAN**.
- PARTS LIST:** LICENSE PAN, ALUMINUM SPACER, SIGNAL BRACKETS, LICENSE PLATE LIGHT MOUNTING BRACKET, TURN SIGNALS, 3 ¼" X ¾" TRUSS HEAD SCREWS, 1 ¼" X 1" TRUSS HEAD SCREW, 2 ¼" X ½" PAN HEAD SCREWS, 3 WASHERS, 6 ¼" NUTS, ½" ALUMINUM TUBE.

VIEW OF UNDER ENCLOSURE

