

<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>

PARTS LIST:

1- GP Exhaust Canister 1- 2.25" Clamp

REMOVAL:

- 1) Remove stock exhaust canister (1- bolt, 1- clamp).
- 2) Remove spacer from rubber mounting grommet to avoid loss.

INSTALLATION:

- 1) Install WerkesUSA GP Canister with supplied 2.25" Clamp.
- 2) Adjust to desired fit and clearance. Tighten securely.
- 3) Clean with WD-40 (or similar) before starting. This will ensure uniform coloring.

PERIODICALLY:

- 1) Check clamp.
- 2) Clean with WD-40 (or similar) to prevent grime build up.

****IMPORTANT**** To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle ****IMPORTANT****



The purchaser releases Competition Werkes Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.