



<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>

**(800)736-2114**

# BMW R nineT

## slip-on exhaust

REMOVAL: 1) Stock exhaust canisters (1- T40 bolt, 1- T45 clamp).

INSTALL: 1) WerkeUSA canister using supplied clamp, stock bolt with supplied washer and nut.  
2) Clean canister with WD-40 or similar product before starting.  
3) Clean canister and check hardware periodically.

### PARTS LIST:

1- WerkeUSA Canister 1- 2.5 Clamp 1- 8mm Washer 1- 8mm Nut

**\*\*IMPORTANT\*\*** To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle **\*\*IMPORTANT\*\***



The purchaser releases Competition Werkes Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.

WB1200