



<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>

(800)736-2114

2013 Ducati Hypermotard slip-on exhaust

- REMOVE:** Stock exhaust canister (1- bolt, 1-clamp).
- INSTALL:** WerkesUSA exhaust canister using supplied 8x25 Allen Bolt , 8mm Washer, and stock clamp. Tighten all hardware and clamp
- CLEAN:** WerkesUSA exhaust of fingerprints and grime with WD-40 or similar product.

PARTS LIST:

- 1- WerkesUSA Canister 1- 8x25 Allen Bolt 1- 8mm Washer

****IMPORTANT**** To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle ****IMPORTANT****



The purchaser releases Competition Werkes Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.

WDHYP2M-S