



PARTS LIST:  
1- Exhaust Canister  
1- 6x20 Allen Bolt  
1- 6mm Washer

<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>

**(800)736-2114**

## **Slip-on Exhaust**

### REMOVAL:

- 1) Remove stock exhaust canister (1- spring, 2- bolts).

### INSTALL:

- 1) Slip WerkesUSA canister onto stock piping. Secure with stock spring and supplied 6x20 Allen Bolt, supplied washer (behind bracket), and one of your stock nuts.
- 2) Clean exhaust with WD-40 (or similar product).

**\*\*IMPORTANT\*\*** To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle **\*\*IMPORTANT\*\***



The purchaser releases Competition Werkes Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.

WDSCR