



<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>

(800)736-2114

HONDA GROM

FULL GP EXHAUST



****IMPORTANT**** To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle ****IMPORTANT****

- 1) Remove stock exhaust (2- nuts at head, 2- bolts below, and 1 bolt/nut at rearset).
- 2) Install WerkesUSA Head pipe with supplied 8mm Flange Nuts at head (leave loose) and supplied 8x16 Bolts with 8mm Washers below engine *Loc-tite recommended* (leave loose).
- 3) Install WerkesUSA Canister with stock hardware at rear set and supplied Spring.
- 4) Tighten all hardware.
- 5) Wipe clean with WD-40 or silmilar before starting.

PARTS LIST:

1- Canister	1- Head-pipe	1- Spring
2- 8mm Flange Nuts	2- 8x16 Allen Bolts	2- 8mm Washers

The purchaser releases Competition Werkes Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.

WH126