



<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>

**(800)736-2114**

## **2015 Honda CBR300r GP Exhaust**

**REMOVAL:** 1) Remove stock exhaust canister (1- bolt at rear peg, 1- clamp). Remove gasket.

**INSTALL:** 1) Install WerkesUSA GP Exhaust using supplied clamp.  
2) Adjust for swingarm and brake lever clearance. Tighten clamp securely.  
3) Clean exhaust of fingerprints and grime using WD-40 (or similar).

### **PARTS LIST:**

1- GP Exhaust Canister 1- 1 5/8" Clamp

**\*\*IMPORTANT\*\*** To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle **\*\*IMPORTANT\*\***



The purchaser releases Competition Werkes Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.

**WH300**