

<><<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>

(800)736-2114

THUSOVARINA Vitipilen/Svartipilen 701 GP Slip-on Exhaust

REMOVAL:

- 1) Loosen exhaust clamp (see image).
- 2) Remove bolt at rear foot rest (see image)
- 3) Remove stock exhaust canister.

PARTS LIST:

- 1- GP Slip-on
- 1-8x30 Allen Bolt
- 1-8mm Nyloc Nut
- 1-8mm Washer

INSTALL:

1) Position and secure WerkesUSA GP Exhaust (use stock clamp, and supplied hardware).



IMPORTANT To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle **IMPORTANT**

The purchaser releases Competition Werkes Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.