



<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>

**(800)736-2114**

# 2021 KTM Superduke 1290

## Slip-on Exhaust

### REMOVAL:

- 1) Remove exhaust valve cover to access clamp.
- 2) Remove stock exhaust canister (1- bolt, 1- clamp)

### INSTALL:

- 1) Install WerkesUSA GP Exhaust Canister using stock hardware and clamp.
- 2) Replace exhaust valve cover (remove grommet to prevent loss).
- 3) Clean exhaust canister with WD-40 (or similar) before starting.



**\*\*IMPORTANT\*\*** To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle **\*\*IMPORTANT\*\***

### PARTS LIST:

- 1- WerkesUSA GP Exhaust Canister

The purchaser releases Competition Werkes Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.

**WKT1292**