



<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>

(800)736-2114

2017 KTM 390 DUKE

- REMOVE: 1) Remove stock exhaust canister [1- bolt 1 clamp].
- INSTALL: 1) Install WerkesUSA GP Canister at stock location with bracket to backside of mount (use stock bolt and clamp).
2) Clean exhaust with WD-40 (or similar) before starting.

PARTS LIST:

- 1- WerkesUSA GP Canister

****IMPORTANT**** To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle ****IMPORTANT****



The purchaser releases Competition Werkes Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.

WK392