



<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>

(800)736-2114

# KTM 790 Duke

*Slipon Exhaust*

REMOVE: Stock exhaust canister (1bolt, 1 clamp).

INSTALL: WerkesUSA Exhaust Canister (1-bolt, 1- clamp).

CLEAN: Using WD-40 (or similar) wipe exhaust free of fingerprints.

1- Exhaust Canister

1- 8mm Ny-loc Nut

**\*\*IMPORTANT\*\*** To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle **\*\*IMPORTANT\*\***



The purchaser releases Competition Werkes Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.

WKT790