



www.werkesusa.com (800)736-2114

06-07 TRIUMPH Speed Triple

<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>

- REMOVE: Stock exhaust.
- REMOVE: Lower bolt from right rearset. *PHOTO*
- LOOSEN: Upper bolt on right rear set.
- INSTALL: WerkesUSA GP canister. (slide mount behind rearset)
- TIGHTEN: Both bolts and clamp.
- CLEAN: Canister with WD-40 or similar product.
- CHECK: Rear brake for clearance and proper function.

NOTE Place washer as a spacer behind rearset upper bolt.



****IMPORTANT**** To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle ****IMPORTANT****

The purchaser releases Competition Werkes Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.

WT1049-S