



<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>

(800)736-2114

Triumph
ROCKET 3

REMOVAL:

- 1) Remove right heel guard (2-bolts).
- 2) Remove muffler heat shield (1- bolt, slide forward).
- 3) Remove stock exhaust muffler assembly (1- clamp, 3- bolts, carefully pull away and unscrew O2 sensor).
- 4) Remove bushing from center exhaust bolt location and store with your stock exhaust.

INSTALLATION:

- 1) Carefully transfer stock exhaust flange gasket to the WerkesUSA exhaust.
- 2) Install O2 sensor to back of y-pipe portion of the upper WerkesUSA canister.
- 3) Clamp upper WerkesUSA canister onto stock headpipe (leave slightly loose until after next step).
- 4) Install lower WerkesUSA canister (use stock bolt/nut, and supplied clamp) Adjust/align exhaust canisters as desired before tightening clamps and hardware securely.
NOTE The clamps and mounting hardware/bracket all work together to support your WerkesUSA exhaust system. Tighten them securely. Check periodically (we recommend every 1000 miles).
- 5) Transfer u-nut from stock heatshield mount to the WerkesUSA exhaust.
- 6) Install stock heat shield using stock hardware.
- 7) Install heel guard.
- 8) Clean exhaust of fingerprints and grime using WD-40 (or similar) before starting.

PARTS LIST:

1- Upper Exhaust Canister 1- Lower Exhaust Canister 1- 2" Clamp

****IMPORTANT**** To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle ****IMPORTANT****



The purchaser releases Competition Werkes Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.

WT2500