



<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>

**(800)736-2114**

# Triumph Street Triple 765

- REMOVAL:
- 1) Remove heat shield from lower left side to gain access to clamp (1- bolt, slide forward).
  - 2) Remove stock exhaust canister (2- bolts, 1- clamp) slide rearward off head-pipe.
  - 3) Remove remaining gasket and flange from head-pipe.
- INSTALLATION:
- 1) Install WerkesUSA GP Canister using stock bolt/nut at rearset and supplied clamp.
  - 2) Clean exhaust of fingerprints and grime with WD-40 (o similar) before starting engine.

#### PARTS LIST:

1- GP Exhaust Canister      1- 1.75" Clamp

**\*\*IMPORTANT\*\*** To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle **\*\*IMPORTANT\*\***



The purchaser releases Competition Werkes Inc. from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.

WT765