



www.werkesusa.com  
(800)736-2114

<<<<<< IT IS RECOMMENDED THAT THIS PRODUCT BE INSTALLED BY A QUALIFIED TECHNICIAN >>>>>>

## 03-05 Yamaha R6/06-08 Yamaha R6s

- REMOVE: Stock canister (1 bolt in rear footpeg mount and 1 clamp at seam).
- REMOVE: Plastic spacer from swing arm (2 allen bolts).
- INSTALL: WerkesUSA GP canister with supplied clamp (tighten until canister is completely solid)
- CLEAN: With WD-40 (or similar) before riding to insure color fastness.
- \*NOTE\* Check clamp periodically for tightness.

PARTS LIST: 1- WerkesUSA GP Canister 1- 2.125" Stainless Steel Clamp

**"IMPORTANT"** To insure uniform coloring thoroughly clean with WD-40 or like product before starting motorcycle **"IMPORTANT"**



The purchaser releases Competition Werkes inc from all liabilities pertaining to the installation and use of purchased parts. Purchaser recognizes that any alteration and/or modifications to the vehicle may increase the risk of injury or accident, and may also render the vehicle illegal for use on public roads.