



United States Patents
 US 0748,739 S US 9,145,154 B1
 US 0757,637 S

Europe Registered Community Design No
 003423193-0001
 003395656-0001

TITANIUM SERIES ASSEMBLY INSTRUCTIONS

Video Instructions: <https://www.youtube.com/watch?v=RGTi01I9Z60>
 Safety Harness: https://www.youtube.com/watch?v=Y_CxX2JB5DQ

WAGON SET-UP INSTRUCTIONS

Step 1



Slide Rear Wheel into Rear Wheel Bracket and line up the axle holes. Make sure the inside of the wheel with all of the holes for the brakes in the circular pattern are pointed inward.

Step 2



Insert Long Bolt through Rear Wheel Bracket and Rear Wheel. Slide Rear Brake onto Long Bolt and tighten Long Bolt. Repeat for both Rear Wheels.

Step 3



Insert Springs into Rear Wheel Bracket spring cups. Both sides.

Insert screwdriver through holes on Rear Wheel Bracket and push down to seat Springs.

Step 4



Turn Wagon upside down on clean flat surface and connect Rear Wheel Bracket to Rear of Wagon Frame.

Step 5



Align bolt holes then insert Short Bolts and tighten.

Step 6



Cover all four holes with Caps.

Step 7



Insert Front Wheels into Wagon Frame. Be sure Red Spring is pointing toward the rear and Brake Lever is pointed inward toward center of Wagon.

Step 8



Tighten set screw to secure Front Wheel to Wagon Frame. Both sides.

ENJOY!!



CARE: Use a damp cloth to clean. Do not use chemicals.

HELPLINE: 1-949-381-7367
EMAIL: SALES@CUSTOMFOLDINGWAGONS.COM

MADE IN CHINA



United States Patents
 US 7,748,739 S US 9,145,154 B1
 US 7,757,637 S

Europe Registered Community Design No
 003423193-0001
 003395656-0001

TITANIUM SERIES ASSEMBLY INSTRUCTIONS

Video Instructions: <https://www.youtube.com/watch?v=RGTi01I9Z60>
 Safety Harness: https://www.youtube.com/watch?v=Y_CxX2JB5DQ

BOX CONTENTS



1x FOLDING WAGON

HOW-TO INSTRUCTIONS HERE:



CARE: Use a damp cloth to clean. Do not use chemicals.

HELPLINE 1-949-381-7367
 EMAIL: SALES@CUSTOMFOLDINGWAGONS.COM

MADE IN CHINA