

VALLKREE ASSEMBLY INSTRUCTIONS



CONGRATULATIONS ON YOUR NEWLY PURCHASED VALLKREE E-BIKE.

The following instructions are for assembly of your flat-packed delivered VALLKREE Bicycle. Please follow each step carefully.



DISASSEMBLED FROM THE BICYCLE FRAME WILL BE:

- The front wheel
- The handlebars
- The pedals 1pcs
- The headlight
- The front mudguard
- The Chainguard

1 BOX CONTAINING:

- The battery charger 1pcs
- Battery tank key 1pcs
- The front wheel axle pin 1pcs

TOOLS REQUIRED:

- 10mm Spanner
- 4mm Allen Key
- 5mm Allen Key
- Scissors
- Bicycle Grease



1

First, assemble handlebars



2

Adjust to required riding position



3

Fit mudguard onto the rear fork hole



4

Put front wheel on



5

Lean bike on stand



6

Insert and tighten front axle pin



7

Attach headlight on front fork



**In approximately one month after purchase/riding, the bike needs all the nuts and bolts checked and retightened, the one month is a 'wearing in period'...*



8

Connect the two wire plugs



9

Screw in the one peddle towards the front of the bike, and tighten



10

Add chain gaurd



11

Push the button underneath to operate, needs sun to recharge



12

Your bike is ready to cruise, enjoy!

...There after regular checks and maintanance are very important for safety.