



# ***SIDECAR/CARGO BIKE ASSEMBLY INSTRUCTIONS***



**1**

*Flat-packed parts*



**2**

*Put the mud guard on*



**3**

*Put the axle pin into wheel centre*



**4**

*Put wheel on*



**5**

*Fix base plate to bike in correct position*



**6**

*Attach the 3 u-bolts and fasten the nuts*



**7**

*Fix sidecar capsule to base with the 6 bolts and nuts provided, then tighten*



**8**

*If desired fit seat into capsule with the 4 bolts provided, from the underneath*

