



Assemble using bolt kits provided, button bolt from inside tray to outside using a washer between wingnut and aluminium the only difference between the rear and front support bolt kits are the two stainless washers which are to be used between the sluice and hopper to avoid binding of the aluminium.

If you have a sluice without the new holes simply use our stencil to drill 6mm holes to your needs.

The perf plate can be placed to suit your needs, we like to leave some overhang to clear the rear of the sluice.

If you have any questions at all please call any time 07 3284 0165



You will note each mount has three settings, this allows variation in hopper fall and tilt from the rear. Using the lowest setting here allows the full clearance of your hopper to rest inside the sluice channel.



GOLD
PROSPECTING
EQUIPMENT



RAT
HIGHBANKERS
SLUICES
MATTING
HIGHBANKER.COM.AU

