

Installation Instructions for BAI One Piece Toilets

1. Clean the area around the toilet flange for the BAI Toilet installation. Using a plastic putty knife avoids damaging the floor when scraping up construction debris. Remove old traces of wax from the flange with a rag dabbed in isopropyl alcohol.
2. Remove plastic decorative covers from each side of the toilet.
3. Move the skirted toilet into position over the flange. Check that the water-supply valve isn't in the skirt's way. If so, have the supply valve moved by a professional plumber.
4. Insert the flange bolts, threads pointing upward, into the flange parallel with the wall behind the toilet.
5. Press supplied wax ring into the flange opening's center.
6. Lower the BAI toilet bowl over the flange until the bolts emerge from the holes on either side of the base (look through opening on each side of the toilet).
7. Secure the toilet from each side through the windows to the flange by tightening the flange bolts in place. Close the plastic decorative covers.
8. Wrap the water supply inlet with plumber's tape. Connect the water supply hose.
9. Turn on the water supply at the valve. Flush the BAI skirted toilet and check that it works correctly. Tighten any bolts or the inlet coupling if needed.