

## Heavy Duty Divan (with / without Drawers) - Assembly Instructions

- Remove packaging. Locate and remove the kit bag containing the fittings.
- This will be attached to the bottom of the divan or on the inside of a drawer.
- Place the divan on its side or face down to gain access to the sockets underneath.
- In each corner (and the centre for singles) you will see a metal socket, place the glide/castors into the sockets and apply force.
- Once all the castors/glides are attached, stand the divan upright on them.
- **For split divans:**
  - Push both halves together making sure they line up, ensuring the square corners go together.
  - On the sides, not ends, you will see some 'Insert Here' stickers marking the location of the threaded holes.
  - Gently pierce the fabric where marked.
  - Attach the link bars using the wing head bolts.
- For drawer divans, please remove the fabric that secures them shut when in transit.
- Divans will have headboard holes at both the head & foot end making the product universal, these are also marked with 'Insert Here' stickers. Only pierce the fabric at the end you wish to attach your headboard.

