Radiator Fitting Instructions

The installation of our Contemporary Floating Radiator Covers with Shelves is very simple and you do not need practically tools, just a 8mm drill and a bit. Follow the instructions below and in 10 minutes you will have your radiator perfectly installed.

