



First Step will be to remove the black panel from the Swing Gate. Give a light tug on the fabric cable loom so it applies a little pressure to the panel. This will either pop off the first clip, or make a gap large enough for you to grab the perimeter of the panel. Work your way around the outside of the panel pulling straight out as you go in order to remove the swing gate panel.

Once the panel is removed look to see if any green clips are still in the door. If so pinch the green clip together and pull them out. As you remove any remaining clips place them on the corresponding tabs of the black panel to ensure a smooth reinstallation later.



Using the Bottle opener as a guide, position it on the swing gate as shown. (note the top of the bottle opener is about  $\frac{1}{4}$ " down from the lip for the JL Badge). Use a Marker to mark the center of your top hole.

Set the bottle opener aside and use the supplied drill to make your first hole on the center mark.

armorautoparts.com  
sales@armorautoparts.com  
616-414-1099

Once the top hole is drilled you will take one bolt, slide it through the top hole of the bottle opener and through the hole you just drilled. Reach in to the back of the bolt with one of the serrated nuts and thread it onto the bolt. With one hand hold onto the nut and the other hand use the Allen Wrench from the kit to tighten the top bolt. (at this point be sure the bottle opener is positioned where you want as you will use the bottom hole of the bottle opener as your second drill hole guide) (Also with the nut being serrated a wrench shouldn't be needed on the nut as once it starts to tighten the serrations will bite and it will hold.)



With the drill bit supplied in the kit, and the top bolt of the bottle opener holding it in the position you want, use the bottom opening on the bottle opener as a guide to drill the lower hole. Once the hole is drilled insert the 2<sup>nd</sup> bolt through the opener and hole and reach behind to thread on the 2<sup>nd</sup> nut. Hold the nut in place with your hand as you tighten the bolt (again a wrench shouldn't be needed on the nut as the serrations will start to bite and hold the nut stationary as you tighten with the supplied allen wrench)



Line up the clips of the black panel with the corresponding openings in the swing gate.

Work around the perimeter of the black panel pushing straight in to reinstall the black panel.

Job well done. Enjoy!

