

FOCUS MK2.5 (Face-lift) BONNET STRUT KIT



This kit will fit ALL MK2.5 face-lift models 2008 onwards



Kit brackets



Start on drivers side, unclip header tank and move to side for better access to inner wing.



the slotted section on the wing bracket fits into the inner wing (red circle)



insert bracket into wing (red circle) at shown angle (right angle piece of metal is just to demonstrate how bracket locks into inner wing)



once fully in, tab should lock in at bottom. Bolt and lock nut in bracket should now line up with oval hole in inner wing.



Use a small Allen key or small screwdriver to hold, locking nut in position. Position lock nut at end of bolt (leave 1 or 2 threads so lock nut doesn't come off bolt).



With the Allen key or screwdriver through the lock nut, wiggle the lock nut inside the oval hole in the inner wing.



Tighten nut with 10mm Spanner, keep Allen key in place until locknut tightens, DO NOT over tighten.



Repeat process on passenger side , undo fuse box securing bolt to allow more access to inner wing as before.



Fit bracket as shown, refit nuts , check bonnet position is correct then fully re-tighten nuts.



Then fit remaining bonnet bracket as before.



Remove small retaining clip from each ball socket on the strut and fit strut to brackets. Body of strut (wide section) must be uppermost as pictured to avoid strut oil seal from drying out and leaking. Once in place refit securing clips to ball sockets.



Repeat on opposite side.



Finished look (Due to the unique design of our wing brackets, the inner wing covers don't require any holes cutting, as with other kits)

