



PERFORMANCE EXHAUST

A PerTronix Performance Brand ~ www.pertronixbrands.com ~ 909 599-5955

Installation Instructions & Warranty Information

30-2688 / 40-2688 2015-21 Mustang Eco Boost

3" Axle Back Exhaust



This product is considered a Replacement part per CARB and EPA regulations for emissions compliance and is legal for sale and use on all vehicles in all 50 states when installed according to the Manufacturer's Application Guide and Installation Instructions.

⚠ WARNING:

This product can expose you to chemicals including Lead, Nickel, Cadmium and Chromium which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov

PLEASE READ BEFORE PROCEEDING

PerTronix® thanks you for choosing a JBA Performance Exhaust Product. To realize the potential of JBA's engineering and excellent fit, Please Read and Understand these instructions completely prior to starting the installation.

Check that you received all the parts listed on the parts list, if you have any concerns, please contact PerTronix before continuing.

Work Smart – Work Safe! Most Exhaust Installations are best performed on a lift. If a lift is not available, raise the vehicle and support on quality Jack Stands on level ground. Do not rely on a jack!

Before starting, allow the vehicle to cool, disconnect the battery, and spray penetrating oil on all hardware and fittings that will need to be removed. Silicone spray on rubber hangers will make them easier to remove and install.

INSTALLATION:

1. Remove the JBA Exhaust System from the box and make sure all parts are there before starting.
2. There is a small heat shield on each exhaust pipe just forward of the rear axle. At each end there is a small clamp. Cut this clamp, and bend the shield out of the way.
3. Measure 5" from the middle of the bend as shown in the picture and mark a line. This is where you will cut the stock mufflers off the mid pipe. Shown with the mid pipe on the ground but you can do this in the car. Cut the pipes being careful to keep the cut square.



4. Using pliers or a pry bar, slide the rubber hangers from the hanger rod on the muffler and tailpipe (a little WD40 helps). Remove the mufflers from the car.
5. Slip one 2 1/4" clamp over each section of the midpipe. Slide the JBA muffler assemblies over the mid pipe and the hangers into the rubber isolators on each side. WD40 or similar will make this easier.

6. Place a clamp on each tip and then slide the tips onto the muffler. Adjust the tips an equal distance from the bumper cover. When you are satisfied with the placement, tighten the clamps securely.

7. Using a soft cloth and polish, remove any finger prints or oil from to tips before starting to eliminate staining.

JBA also offers a complete Cat back system and a 3" Cat Back Turbo Down Pipe for the ECO-Boost Mustang. See www.pertronixbrands.com for more info



Parts List:

- 1 Drivers side muffler assy.
- 1 Pass side muffler assy.
- 2 2 1/4" Accu Seal Clamps

JBA LIMITED WARRANTY

All JBA Headers and Exhaust products are guaranteed, to the original purchaser, to be free of defects in materials and workmanship for one year. This warranty covers the replacement or repair of the product only and does not cover the cost of removal and installation, customer applied aftermarket coatings or any discoloration or corrosion of finished surfaces.

Damage or product failure resulting from collision, improper installation, off-road use, road hazards, the use of exhaust insulating wrap or like products or rust occurring after installation, is not covered by the warranty. The warranty extends only to the original purchaser.

Should a part become defective it should be returned to the original selling retailer and must be accompanied with the sales receipt. If there is no retailer in your area, call the factory for a return authorization and return your part prepaid to the factory for inspection. PerTronix reserves the rights to replace or repair the alleged defective part and return the part freight collect.