

A PerTronix Performance Brand ~ <u>www.pertronixbrands.com</u> ~ 909 599-5955

Installation Instructions & Warranty Information 40-2527 ~ 2010-2014 Ford F-150 Raptor 6.2L 3" Dual Tip Cat Back Exhaust





This product is considered a Replacement part per CARB and EPA regulations for emissions compliance and is legal for sale and use on all vehicles in all 50 states when installed according to the Manufacturer's Application Guide and Installation Instructions.

## 🛝 WARNING:

This product can expose you to chemicals including Lead, Nickel, Cadmium and Chromium which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov

## PLEASE READ BEFORE PROCEEDING

PerTronix<sup>©</sup> thanks you for choosing a JBA Performance Exhaust Product. To realize the potential of JBA's engineering and excellent fit, Please Read and Understand these instructions completely prior to starting the installation.

Check that you received all the parts listed on the parts list, if you have any concerns, please contact PerTronix before continuing.

Work Smart – Work Safe! Most Exhaust Installations are best performed on a lift. If a lift is not available, raise the vehicle and support on quality Jack Stands on level ground. Do not rely on a jack!

Before starting, allow the vehicle to cool, disconnect the battery, and spray penetrating oil on all hardware and fittings that will need to be removed. Silicone spray on rubber hangers will make them easier to remove and install.

- 1. Remove the clamp that holds the front of the muffler to the stock Exhaust Pipe.
- Remove the muffler from the rear section of the exhaust. You will probably have to cut the pipe.
- Remove the remainder of the original exhaust system by careful prying the hangers from the rubber mounts. WD40 will really help.
- 4. Mount the over axle pipe to the truck using the two hangers that are on the pipe to the original rubber mounts.



5. Slide one of the clamps over the muffler outlet then slip the muffler onto the over axle pipe and mount the muffler to the forward hanger on the frame. Do not tighten the clamp at this time.



6. Slide one of the clamps over the muffler inlet then slip the New JBA S Shaped pipe into the muffler and the stock <u>forward pipe</u>.



7. Slide one of the clamps over the inlet side of the rear Tip pipe. Slip the pipe onto the over axle pipe.



8. Check that the muffler and intermediate pipe are straight and square to the frame. Tighten the clamp at the inlet side of the muffler.

 9. Check the alignment of the over axle pipe making sure it is clear of any hoses or wiring.
Tighten the clamp at the outlet of the muffler once everything is aligned. 10. Align the rear Chrome Tip pipe so that it clears the body and look aesthetically pleasing. Once you are satisfied with the position, tighten the clamp.



11. Check to make sure that everything is clear of any hoses or wiring, and the spare tire.

12. Check that all clamps are good and tight.

13. Take the truck for a short test drive and check for leaks and rattles. If everything is correct, we strongly recommend that you tack weld all the connections to insure that they do not work loose while driving.

### NOTES:

1. All exhaust systems expand about 1" rearward when exhaust temperature rises. Keep this is mind when mounting components.

2. Use anti-seize on threads of clamps.

#### Parts List

- 1 3" Intermediate 'S' Pipe
- 1 3" Over Axle Pipe
- 3 Exhaust Clamps

- JBA Stainless Muffler
- Dual Chrome Tip Pipe
- Double Wire Clamp

# JBA LIMITED WARRANTY

1

1

1

All JBA Headers and Exhaust products are guaranteed, to the original purchaser, to be free of defects in materials and workmanship for one year. This warranty covers the replacement or repair of the product only and does not cover the cost of removal and installation, customer applied aftermarket coatings or any discoloration or corrosion of finished surfaces.

Damage or product failure resulting from collision, improper installation, off-road use, road hazards, the use of exhaust insulating wrap or like products or rust occurring after installation, is not covered by the warranty. The warranty extends only to the original purchaser.

Should a part become defective it should be returned to the original selling retailer and must be accompanied with the sales receipt. If there is no retailer in your area, call the factory for a return authorization and return your part prepaid to the factory for inspection. PerTronix reserves the rights to replace or repair the alleged defective part and return the part freight collect.