


A PerTronix Performance Brand ~ www.pertronixbrands.com ~ 909 599-5955

Installation Instructions & Warranty Information 40-3048 ~ 2007-08 Chevrolet Trailblazer SS Cat Back Exhaust



PerTronix[©] thanks you for choosing a JBA Performance Exhaust Product. To realize the potential of JBA's engineering and excellent fit, Please Read and Understand these instructions completely prior to starting the installation.

Check that you received all the parts listed on the parts list, if you have any concerns, please contact PerTronix before continuing. Headers will have the part number stamped in the flange.

Work Smart – Work Safe! Most Header and Exhaust Installation are best performed on a lift. If a lift is not available, raise the vehicle and support on quality Jack Stands on level ground. Do not rely on a jack!

WARNING:

This product can expose you to chemicals including
Lead, Nickel, Cadmium and Chromium which are known to the
State of California to cause cancer and birth defects or other
reproductive harm. For more information go to
www.P65Warnings.ca.gov

Start:

- Remove and inventory new JBA exhaust system.
- Disconnect negative battery cable and allow vehicle to cool.



 With vehicle raised and properly supported, using a reciprocating saw or hack saw, cut the tail pipe appro_ximately 3" behind the muffler.



 Remove the nuts attaching the intermediate pipe to the catalytic converter assembly using a 9/16" deep socket.



- Spray lubricant on the intermediate pipe hanger grommet and then remove the pipe.
- Install the new intermediate pipe (A) into the hanger grommet.



 Using a 9/16" deep socket, attach the intermediate pipe to the catalytic converter assembly.



 Install the new JBA muffler
 onto the intermediate pipe
 and then position the 3" clamp over slip connection.





 Spray lubricant on the rear hanger grommet. Remove the rear hanger from the grommet using a pair of channel lock pliers.



Remove the tail pipe and rear muffler assembly from the rear of the vehicle.



 Install the new tail pipe (C) over the rear axle with the hanger closest to the muffler.



 Insert the tail pipe hanger into the rubber grommet behind the muffler.



 Slip the tailpipe (C) together with the muffler (B) outlet. Attach the 3" clamp over the connection.



 Slip 3" clamp with hanger (X) over the end of tail pipe (C).
 Install hanger into rear hanger grommet as shown.



Install the tip with resonator
 onto the end of the the tail pipe (C).



 Align the tip and resonator and slide the 3" clamp with hanger over the slip connection.





- Check for adequate clearance from rear bumper and tighten 3" clamp with hanger.
- Using a soft cloth, remove all prints from exhaust tip.
- Check all clamps and connections for proper fit and alignment. Double check all clamps are tightened.
- Check all clamps and connections for proper fit and alignment. Double check all clamps are tightened.

NOTES:

- It may be necessary to loosen and realign the spare tire for proper clearance.
- All exhaust systems expand about 1" rearward when exhaust temperature rises.
- Use anti-seize on threads of clamps.

Parts List:

A. Head pipe with hanger	1	B.	Muffler	1
C. Tail pipe with hanger	1	D.	Tip with resonator	1
E. Front muffler clamp 3"	2	F.	Rear muffler clamp/hanger 3"	1



This product is considered a Replacement part per CARB and EPA regulations for emissions compliance and is legal for sale and use on all vehicles in all 50 states when installed according to the Manufacturer's Application Guide and Installation Instructions.

JBA LIMITED WARRANTY

All JBA Headers and Exhaust products are guaranteed, to the original purchaser, to be free of defects in materials and workmanship for one year. This warranty covers the replacement or repair of the product only and does not cover the cost of removal and installation, customer applied aftermarket coatings or any discoloration or corrosion of finished surfaces.

Damage or product failure resulting from collision, improper installation, off-road use, road hazards, the use of exhaust insulating wrap or like products or rust occurring after installation, is not covered by the warranty. The warranty extends only to the original purchaser.

Should a part become defective it should be returned to the original selling retailer and must be accompanied with the sales receipt. If there is no retailer in your area, call the factory for a return authorization and return your part prepaid to the factory for inspection. PerTronix reserves the rights to replace or repair the alleged defective part and return the part freight collect.